

Молния

PRODUCT CERTIFICATE

ACHS-1 • VERSION 5.1



1 – hour hand

2 – minute hand

3 – second hand

4 – three-position winding

crown

I – neutral position

II – position 2

III – position 3

DESCRIPTION, DISPLAYS AND FUNCTIONS

The AChS – 1 5.1 wristwatch is a timepiece with an automatic winding mechanism.

1. SETTING THE TIME

Pull the winding crown out into position III.

Turn the winding crown counterclockwise to set the current time.

Push the winding crown back into its original position. The second hand will start moving.

2. SETTING THE CURRENT DATE

Pull the winding crown out into position II.

Turn the winding crown counterclockwise to set the current date.

Push the winding crown back into its original position.

Do not set the date between 21.00 and 01.00. This could damage the watch movement.

3. WINDING

Automatic winding

Constant arm movements cause the rotor to pivot, activating the self-winding mechanism.

Manual winding

When using the watch for the first time or if it has not been worn for a long period, the watch should be wound 8-10 times by rotating the winding crown clockwise.

During subsequent use, the winding crown should be rotated 40 times in order to fully wind the watch manually.

The power reserve is approximately 42 hours.

INSTRUCTIONS FOR USE, CARE AND STORAGE

The AChS-1 5.1 wrist watch features an automatic winding watch movement.

1. WATER RESISTANCE

The AChS-1 Version 5.1 is water resistant to 10 ATM, a standard measurement which means the watch can withstand a pressure of 10 atmospheres.

These watches are resistant to splashes and rain, and you can wash your hands wearing the watch. You can swim while wearing the watch and it can be submerged in water. However, these watches are not suitable for scuba diving.

2. CARE

We recommend that you clean your watch regularly (apart from the leather strap) with a soft cloth moistened with warm soapy water.

3. PRECAUTIONS

- Never attempt to open the case or remove the back cover yourself.
- The rubber seals protecting the watch from water and dust are to be replaced every 2-3 years.
- If any moisture gets inside the watch, immediately have its condition checked by an authorized service center.
- Do not expose the watch to extreme temperatures.
- Do not handle the watch roughly (shocks, drops etc.).
- Do not fasten the strap too tight. There should be a finger-wide gap between the wrist and the strap.
- The watch should be stored in a dry place.
- Keep the watch away from gasoline, cleaning solvents, aerosols from sprayers, adhesives, paints, etc. Chemical reactions caused by these materials can damage the seals, the case and finish of the watch.
- The sapphire crystal is strong, but it may crack if the watch falls or receives shock.
- Avoid storing your watch with jewelry containing diamonds, as these can damage the sapphire crystal.

- Store your watch in a separate, preferably specially designed case, lined with a soft protective material.

TECHNICAL SPECIFICATIONS

Case diameter	44 mm
Case material	Steel 316L
Strap width	22 mm
Type of glass	Sapphire crystal
Movement mechanism	Miyota 8215 auto-winding movement, 21 jewels
Function	Date, Stop second
Accuracy	-20 ... +40 seconds per day
Power reserve	42 hours
WR	10 ATM

WARRANTY CONDITIONS

In accordance with Resolution of the Government of the Russian Federation of 27.05.2016 No. 471 On Amendments to Certain Acts of the Government of the Russian Federation on the Return or Exchange of Technically Complex Goods, this product belongs to the category of technically complex goods, which are not subject to the requirement of the buyer to provide him or her with a similar item free of charge for the period of repair or replacement, and which are not subject to return or exchange for a similar item of a different size, shape, size, shape, style, color or configuration.

The warranty only applies to products purchased from authorized sales outlets.

The manufacturer's warranty is 1 (one) year from the date of the product's sale. The warranty covers defects and errors in the assembly materials. In the event of a fault within the warranty period, the manufacturer undertakes to eliminate any faults or malfunctions free of charge. If the repair fails to return the watch to its previous quality, the manufacturer guarantees that it will replace the watch with another of the same model or a model with identical characteristics. Repairs should only be carried out in authorized

service centers. The contacts of authorized service centers are provided by an authorized sales representative.

EXCEPTIONS

The warranty does not cover:

- the glass and strap;
- defects in the watch caused by its use (e.g. scratches on the glass, changes in color and/or material of non-metallic belts and bracelets, etc.);
- any damage to any part of the watch caused by misuse, neglect, or carelessness (shock, potholes, dents, cracks, etc.);
- any unauthorized repair or unauthorized interference with the watch interior and/or exterior means that the warranty is automatically no longer valid.

WARRANTY CARD

All warranty repair claims must be accompanied by a warranty card filled in by both the buyer and the seller of the watch.

SERIAL NUMBER _____

DATE OF SALE _____

SELLER

Name of trading organization

Address and telephone number of trading organization

PLACE FOR STAMP _____ BUYER

I have read and agree with the operating instructions.

I have no complaints concerning the external
appearance or performance of the watch.

**WARNING! THE WARRANTY CARD IS NOT VALID WITHOUT
THE SELLER'S STAMP!**

Name of the authorized service center

The following work has been performed to repair the watch:

Service centre employee

(Signature, full name)

Date

(Signature, full name)

Owner

(Signature, full name)

Date

(Signature, full name)

8 351 700 13 79

25 Zwilling Street, Chelyabinsk,
454091 Russian Federation

sales@molnija.shop
www.molnija.shop

Молния